PARTS LIST

for

Whirlpool
CORPORATION

30" GAS FREESTANDING RANGE
SEALED BURNER
STANDARD CLEAN OVEN

MODEL
SF317PEYW0

▲W−White
N−Almond

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

Whirlpool CORPORATION
Benton Harbor, Michigan.

7−92 Litho in U.S.A.
© 1992 WHIRLPOOL CORPORATION
Part No. 4371687

CONTROL PANEL PARTS

For Model: SF317PEYW0, SF317PEYN0

(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	4371696	Panel, Control
2	4371539	Clock
3	4371538	Bracket, Timer
4	4371316	Endcap RH
5	4371317	Endccap LH
6	4371537	Deflector, Flue
7		Channel, Support
	4371532	R.H.
	4371533	L.H.
8	4371534	Trim, Wrapper
9	4371535	Trim, Vent
10	4371536	Cap, Filler
11	4371300	Shield, Rear Wall
12	4371295	Cable, Anti−Tip
13	816480	Knob, Clock
14	4371320	Retainer, Timer
15	816703	Switch, Light

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Model: SF317PEYW0, SF317PEYN0

(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	816699	Grate, Burner
2		Top, Main
	4371697	White
	4371698	Almond
3	4371546	Bracket, Hinge LH
4	4371545	Bracket, Hinge RH
5	4371694	Panel, Manifold
6	4371663	Knob, Control (4)
7	4371684	Cap, Burner
8	4371691	Pan, Burner
9	4371589	Screw, Burner Mtg.
10	4371477	Knob, Thermostat
11	4371308	Thermostat
12	816612	Clip, Top
13	4371541	Rod, Support
14		Bracket, Mounting
	4371591	R.H.
	4371592	L.H.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD AND BURNER PARTS

For Model: SF317PEYW0, SF317PEYN0

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF317PEYW0, SF317PEYN0

(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	4371596	Burner, Sealed (See Page 5 For Further Breakdown)
2	816603	Tubing, Burner RF
3	816605	Tubing, Burner RR
4	816604	Tubing, Burner LF
5	816606	Tubing, Burner LR
6	4371026	Pipe, Manifold
7	4371587	Valve, Top Burner
8	4371544	Tubing 3/8
9	4371164	Switch, Ignitor(4)
10	4371261	Tubing, Regulator To Manifold Pipe
11	4371032	Control, Regulator
12	816636	Bracket, Regulator
13	4371313	Valve, Safety
14	816642	Nut, Baffle
15	4371470	Bracket, Valve
16	4371280	Baffle,Oven Burner
17	4371583	Ignitor, Module
18	816625	Ignitor, Oven
20	816602	Plate, Tube(2)
22	4371027	Screw, Valve Mtg.
23	4371069	Brkt,Oven Burn Sup
24	4371284	Burner, Oven

OPTIONAL PARTS NOT INCLUDED

4319116	Conversion Kit (Natural Gas To L.P. Gas)

SEALED BURNER PARTS



Illus. No.	Part No.	DESCRIPTION
1	4371596	Burner, Gas (Assy.)
3	4371599	Screw,Ignitor Brkt
4	4371597	Burner Head
5	816567	Orifice, Burner
6	4371598	Ignitor and Brkt

OVEN PARTS

For Model: SF317PEYW0, SF317PEYN0

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: SF317PEYW0, SF317PEYN0

(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	816669	Spacer,B/S(8)
2		Liner,Oven (Not a Serviceable Part)
3	4371087	Channel,Door Hinge
4	816581	Back,Main
5	816651	Screw,Oven Bottom
6	4371529	Flue
7	816620	Gasket,Flue
9	816595	Burner,Box
10		Panel B/S
	816708	White RH
	816709	White LH
	816672	Almond RH
	816695	Almond LH
11	816650	Screw,Leveler(4)
12	816646	Rack,Oven (2)
13	4371018	Bottom,Oven
14	4371092	Insulation,Back
15	4371091	Insulation,Wrap
18	4371031	Clip, Thermo Bulb
19	816670	Support,Oven
20	4371068	Base,Broiler
21	4371081	Cover,Front
23	816608	Bumper, Door
24	4371543	Shield,Flue
25	4371080	Cover,Plate
26	816614	Cord,Power
27	816618	Fastener,Cord
28	4371288	Cover,Power Cord
29	816758	Fastener, Wire
30	4371306	Shield,Rear Wall
31	4371040	Fastener,T Nut
33	816617	Cover, Hinge(2)
35	816668	Socket, Oven Light
36	4371293	Housing,Oven Light
37	4371303	Bulb, Oven Light
38	4371527	Bracket, Top R.H.
39	4371528	Bracket, Top L.H.
40	816615	Plate, Cover
41	4371033	Fastener, U−Type

DOOR AND BROILER PARTS

For Model: SF317PEYW0, SF317PEYN0

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND BROILER PARTS

For Model: SF317PEYW0, SF317PEYN0

(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	816688	Trim, Oven Door
2	816622	Handle, Door
4	4371310	Glass,Door
5	4371311	Shield,Heat
6	4371126	Insulation
7	816683	Liner,Oven Door
8	4371542	Screw,Handle(2)
9	4371128	Seal,Door
10	4371309	Glass,Rear
11	4371113	Bracket,Hinge LH
	4371114	Bracket,Hinge RH
12	4371117	Fastener,Push Nut
13	4371116	Body,Broiler
14	4371121	Pin,Hinge
15	4371122	Spring,Broiler LH
	4371123	Spring,Broiler RH
16	4371120	Liner,Broiler Door
17	816715	Panel,Drawer
18	4371060	Handle
19	816713	Fastener,Spacer
20	4371084	Glide,Drawer
21	816626	Grid,Broiler
22	816644	Pan,Broiler
23	4371119	Insulation
24	4371063	Screw (2)
25	4371077	Track, Upper (2)
26	4371115	Button,Glide
27	4371062	Screw (5)
28	4371125	Cover, Door Liner